Emotiva Processor
Supported Pronto Remote Codes

Revised September 01, 2006

Basic Information:	Note that all basic information values are in hex!	
First byte	0000	Four zeros to tell Pronto this is a learned code
Frequency	006D	006D for 38KHz (decimal value = 4,145,146/frequency in Hz)
Number of 1 pairs	0000	Four zeroes to denote no single burst code exists
Number of 2 pairs	19	Lead in + 12 bits data + 11 bits !data + lead out = 25 pair
Lead-in	00AB 00AB	Lead-in code (4.5mS on followed by 4.5mS off)
Zero	0015 0015	On/Off burst pair for 0.56mS on followed by 0.56mS off
One	0040 0015	On/Off burst pair for 1.68mS on followed by 0.56mS off
Lead-out Zero	0015 02C1	Burst pair 'zero' to lead out and give enough delay between groups
Lead-out One	0043 02C1	Burst pair 'one' to lead out and give enough delay between groups

Notes:

1. Emotiva code is Lead-in + Data (MSB first) + Inverse of data (MSB first) + Lead-out
2. Codes not listed are not supported

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 Power Toggle	0	000	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Power On	1	001	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Power Off	2	002	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 CD Source Sel	3	003	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 TAPE Source Sel	4	004	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 SAT Source Sel	5	005	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 DVD Source Sel	6	006	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 PHONO Source Sel	7	007	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 TUNER Source Sel	8	008	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 VID1 Source Sel	9	009	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 VCR Source Sel	10	00A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 VID2 Source Sel	11	00B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 Volume Up	12	00C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Volume Down	13	00D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mute Toggle	14	00E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Mute On	15	00F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mute Off	16	010	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Mode up	17	011	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Stereo	18	012	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Pro Logic II	19	013	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	20	014	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0043 02C1	Emotiva	N/A
Unused	21	015	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	N/A
Unused	22	016	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0043 02C1	Emotiva	N/A
Zone 1 Jazz Club	23	017	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Cursor Down	24	018	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Channel Up Tuner	25	019	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Channel Down Tuner	26	01A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 + (Plus)	27	01B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 - (Minus)	28	01C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Unused	29	01D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release
Unused	30	01E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Unused	31	01F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 '0'	32	020	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 '1'	33	021	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release
Zone 1 '2'	34	022	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 '3'	35	023	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release
Zone 1 '4'	36	024	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 '5'	37	025	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release
Zone 1 '6'	38	026	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 "7'	39	027	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release
Zone 1 '8'	40	028	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 '9'	41	029	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 '+10'	42	02A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 All Rear Trim Up	43	02B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 All Rear Trim Down	44	02C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Center Trim Up	45	02D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Center Trim Down	46	02E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Sub Trim Up	47	02F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Sub Trim Down	48	030	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Cursor Up	49	031	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Unused	50	032	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 PARTY Mode	51	033	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Bass Up	52	034	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Bass Down	53	035	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Treble Up	54	036	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Treble Down	55	037	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Tune Up	56	038	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 Tune Down	57	039	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Unused	58	03A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Unused	59	03B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	60	03C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 OSD Info	61	03D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	62	03E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 OSD Menu Full	63	03F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 OSD Exit	64	040	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Dim Setting	65	041	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mode Down	66	042	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 8-CHANNEL Source Sel	67	043	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 AM/FM	68	044	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 AM	69	045	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 FM	70	046	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Tuner Direct	71	047	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 Surround Up	72	048	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Surround Down	73	049	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Sur Back up	74	04A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Sur Back down	75	04B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	76	04C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0043 02C1	Emotiva	N/A
Unused	77	04D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	N/A
Unused	78	04E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	N/A
Zone 1 Enter	79	04F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	80	050	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Unused	81	051	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Power Toggle	82		0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Power On	83	053	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Power Off	84	054	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 CD Source Sel	85	055	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 TAPE Source Sel	86	056	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 2 SAT Source Sel	87	057	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 2 DVD Source Sel	88	058	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 PHONO Source Sel	89	059	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 02C1	Emotiva	Initial Release
Zone 2 TUNER Source Sel	90	05A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 VID1 Source Sel	91	05B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 VCR Source Sel	92	05C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 VID2 Source Sel	93	05D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 [Listen To] MAIN Zone As Source	94	05E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Vol Up	95	05F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Vol Down	96	060	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Mute Toggle	97	061	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Mute On	98	062	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Mute Off	99	063	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Channel Up Tuner	100	064	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Channel Down Tuner	101	065	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 2 Tune Up	102	066	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Tune Down	103	067	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 2 AM/FM	104	068	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 AM	105	069	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 FM	106	06A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Tuner Direct	107	06B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 2 '0'	108	06C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 '1'	109	06D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 '2'	110	06E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 '3'	111	06F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 '4'	112	070	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 '5'	113	071	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 '6'	114	072	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 "7'	115	073	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 2 '8'	116	074	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 2 '9'	117	075	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 '+10'	118	076	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Unused	119	077	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	120	078	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Unused	121	079	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Unused	122	07A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Unused	123	07B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Unused	124	07C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Balance Left	125	07D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Unused	126	07E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Unused	127	07F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Balance Right	128	080	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Unused	129	081	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	N/A
Unused	130	082	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0043 02C1	Emotiva	N/A
Zone 2 Setup Up (Cursor Up)	131	083	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 2 Setup Down (Cursor Down)	132	084	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 + (Plus)	133	085	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 - (Minus)	134	086	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Sub Trim Up	135	087	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Sub Trim Down	136	088	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 Mode Up	137	089	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 Mode Down	138	08A	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 2 OSD Menu Full	139	08B	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 2 OSD Exit	140	08C	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 2 OSD Display Info	141	08D	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mode to PLII MUSIC	142	08E	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Mode to PLII CINEMA	143	08F	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mode to PLII MATRIX	144	090	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Mode to NEO:6 MUSIC	145	091	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mode to NEO:6 CINEMA	146	092	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0043 02C1	Emotiva	Initial Release

Emotiva (OEM) Pronto Codes:

Emotiva Function	Emotiva (Dec)	Emotiva (Hex)	Pronto Code (Cut and paste this value into ProntoEdit)	Supported	Command Supported In Software Version (Or Later)
Zone 1 Mode to DTS LFE MUSIC	147	093	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mode to DTS LFE CINEMA	148	094	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Mode to PLIIx Music	149	095	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Mode to PLIIx Movie	150	096	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release
Zone 1 Dolby/DTS SubMode Up	151	097	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 02C1	Emotiva	Initial Release
Zone 1 Dolby SubMode Down	152	098	0000 006D 0000 0019 00AB 00AB 0015 0015 0015 0015 0015 0015 0015 0015 0040 0015 0015 0015 0015 0015 0040 0015 0015 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0040 0015 0015 0015 0040 0015 0040 0015 0015 0015 0015 0043 02C1	Emotiva	Initial Release